LaMotte

low range PHOSPHATE TEST KIT

Code 3466

TEST PROCEDURE • Code 3466

1

Fill the test tube (0106) to the 10 mL line with sample water.



2

Add one Phosphate LR Testab (6836A) and cap tube.




3

Invert tube repeatedly. Mix until tablet disintegrates.




4

After tablet disintegrates, wait 6 minutes. Invert once to mix, then remove cap.



5

Place tube bottom on the color chart inside the dotted lines. Look down through the tube to determine the results as ppb Phosphate.



Store the kit at room temperature.

*Potential health hazard. Read SDS at lamotte.com.

Emergency information for all LaMotte reagents is available from Chem-Tel (US: 1-800-255-3924) (International: call collect, 813-248-0585).

LaMotte

PO Box 329 • Chestertown • Maryland • 21620 • USA

800-344-3100 • 410-778-3100 (Outside USA)

Visit us on the web at www.lamotte.com

63466 • 10/19