

Code 2979

50 Test Strips

# Total Chlorine





# Insta-Test<sup>®</sup> ANALYTIC

Total Chlorine ppm



Using a cup-size sample, dip strip for **2 seconds**. Remove strip with **pad face up**. **DO NOT SHAKE OFF EXCESS WATER**. With pad still facing up, wait **10 seconds** and **read** the strip. Discard strip after 30 seconds.



View from  
above.

LaMotte Company  
Chester town, MD 21620  
<http://www.lamotte.com>

- | Keep wet fingers out of the bottle.
- | Cap bottle tightly after removing strip.
- | Store in a cool, dry place.

