


Insta-TEST[®]

50 Pool & Spa
Test Strips

- **MPS**
- **ALKALINITY**
- **pH**

 **LaMotte**
Just **DIP & READ!**



Immerse strip for **2 SECONDS**.
Remove with **pads face up**.

SHAKE ONCE TO REMOVE EXCESS WATER.

Read immediately: **MPS > Alk > pH**

*U.S. Patent 6,255,117



View from
above.

Code 2982

Monopersulfate*

MPS



Chlorine & bromine use will add color

Alkalinity ppm

Alk



pH



Purple color indicates excessive sanitizer

- Keep wet fingers out of the bottle.
- Close cap tightly after removing strip.
- In pools, immerse strip to a depth of 6".
- In spas, turn off jets and immerse strip to a depth of 6".
- For best results read in natural daylight.
- Store in a cool, dry place.

Made in
USA

LaMotte Company,
Chestertown, MD 21620 USA
www.lamotte.com/insta



6

3739514252517

Drop holding box and dotted tolerance line