

Code 2996

Nitrite & Nitrate



Insta-Test[®] ANALYTIC

Top pad:

Nitrite
as NO₂-N
ppm



Next pad:

Nitrate
as NO₃-N
ppm



Using a cup-size sample, immerse strip for **2 seconds** and remove with **pads face up. DO NOT SHAKE OFF EXCESS WATER. Wait 60 seconds and immediately compare** to color chart.



- | Keep wet fingers out of the bottle.
- | Cap bottle tightly.
- | Store in a cool, dry place.



LaMotte Company
802 Washington Ave., Chestertown, MD 21620 USA
410-778-3100 • www.lamotte.com

