

Insta-TEST[®] POOL4[®] Plus

50 Pool
Test Strips

- **FREE CHLORINE**
- **ALKALINITY**
- **pH**
- **CYANURIC ACID (STABILIZER)**

LaMotte
Just **DIP & READ!**

Immerse strip for **2 SECONDS**. Remove with **pads face up**. **SHAKE ONCE TO REMOVE EXCESS WATER**. Read immediately:

FCI > Alk > pH > Cya

FCI

Free
Chlorine
ppm

0 0.5 1 3 5 10

Alk

Alkalinity
ppm

0 40 80 120 180 240

pH

6.2 6.8 7.2 7.8 8.4 9.0

Purple color indicates excessive sanitizer


Cya

Cyanuric
Acid
ppm

0 40 100 150 250

For best results, pH must be between 7.0-8.4

LaMotte Company, Chestertown, MD 21620 USA
www.lamotte.com/insta



View from
above.

- Keep wet fingers out of the bottle.
- Close cap tightly after removing strip.
- In pools, immerse strip to a depth of 6".
- In spas, turn off jets and immerse strip to a depth of 6".
- For best results read in natural daylight.
- Store in a cool, dry place.



Code 3032

Made in

