



## HIGH RANGE QAC KIT

DIRECT READING TITRATOR, 0-5000 ppm

CODE 3042-01

QUANTITY	CONTENTS	CODE
15 mL	QAC Indicator Solution	6413-E
60 mL	QAC Titration Solution	6412-H
1	Plastic Tube, 5-25 mL	0715-DRT
1	Syringe, 5 mL	30550
1	Direct Reading Titrator, 0-1,000 Range	0384
1	Brush, Test Tube	0514

\*WARNING: Reagents marked with an \* are considered to be potential health hazards. To view or print a Safety Data Sheet (SDS) for these reagents go to [www.lamotte.com](http://www.lamotte.com). Search for the four digit reagent code number listed on the reagent label, in the contents list or in the test procedures. Omit any letter that follows or precedes the four digit code number. For example, if the code is 4450WT-H, search 4450. To obtain a printed copy, contact LaMotte by email, phone or fax.

Emergency information for all LaMotte reagents is available from Chem-Tel: (US, 1-800-255-3924) (International, call collect, 813-248-0585)

To order individual reagents or test kit components, use the specified code number.

Read the LaMotte Direct Reading Titrator Manual before proceeding. The Titrator is calibrated in parts per million (ppm) QAC; each minor division equals 20 ppm.

NOTE: High water hardness levels above 600 ppm may interfere. A dilute HCl solution may be added to lower the pH to 2-5 to compensate for the interference.

# PROCEDURE

---

1. Use the syringe, or other available device, to add 5 mL of sample water to the test tube (0715). Dilute to 15 mL line with QAC-free tapwater or distilled water.

NOTE: Other sample sizes may be used to extend the range of the test. Use the table below to determine sample size and appropriate multiplication factor for the Titrator reading from Step 5.

Range	Sample Size	Multiply Titrator reading by:
0-5000 ppm	1.0 mL	5
0-2500 ppm	2.0 mL	2.5
0-2000 ppm	2.5 mL	2

2. Add 5 drops of QAC Indicator Solution (6413). Cap and mix. Solution will turn green. Solution will turn brown if no QAC is present.
3. Fill Direct Reading Titrator (0384) with QAC Titration Solution (6412).
4. While gently swirling the tube, slowly press the plunger to titrate until the green tint just disappears and the solution turns brown.
5. Read the test result directly from the scale where the large ring on the Titrator meets the Titrator barrel. If using a sample size other than 5 mL, multiply Titrator result by the appropriate multiplication factor. Record as ppm QAC.
6. Thoroughly wash the test tube with the brush (0514). Rinse with clean water after each test.

## LaMOTTE COMPANY

Helping People Solve Analytical Challenges

802 Washington Ave · Chestertown · Maryland · 21620 · USA  
800-344-3100 · 410-778-3100 [Outside U.S.A.] · Fax 410-778-6394

Visit us on the web at [lamotte.com](http://lamotte.com)

©2021 LaMotte Company | 63042-01 | 8.21