

LEAD SCREENING KIT
Code 5-0140



QUANTITY	CONTENTS	CODE
10	Lead Screening Kit Foil Pouches	8003



*Reagent is a potential health hazard. **READ SDS:** lamotte.com
Emergency information: Chem-Tel USA 1-800-255-3924
Int'l, call collect, 813-248-0585

NOTE: Not for use in low buffer water such as distilled, deionized or reverse osmosis waters.

PROCEDURE

1. Open foil pouch. Use dropper to add exactly 7 drops of water sample to small test vial included in the pouch.

2. Swirl vial gently for 1 minute.
Place on a flat surface.

3. Place Lead Test Strip (8003) in the test vial with arrows pointing DOWN.

4. Wait 10 minutes. Do not disturb the strip or vial during this time.
Red lines will appear on the strip.

5. Take the strip out of the vial and lay it on a flat surface with the arrows pointing to the LEFT. Read result.

RESULTS

NEGATIVE RESULT [less than 15 ppb]: LEFT line, next to number 1, is darker than the RIGHT line, next to number 2 OR if you only see one line the result is negative.

POSITIVE RESULT [greater than 15 ppb]: RIGHT line, next to number 2, is darker than the LEFT line, next to number 1, OR if both LEFT and RIGHT lines are equally dark the result is positive.

Note: If no lines appear, or both lines are very light, the test did not run properly and the result is not valid