

# SALT WATER pH KIT

Code 2159-02 | Octa-Slide 2, pH 7.7-8.4



QUANTITY	CONTENTS	CODE
2 x 30 mL	Cresol Red Indicator	2212-G
2	Test Tubes, 2.5-5-10 mL, plastic, w/caps	0106
1	Salt Water pH Octa-Slide 2 Bar, 7.7-8.4	2165-02
1	Octa-Slide 2 Viewer	1101

To order individual reagents or test kit components, use the specified code number.

\*Reagent is a potential health hazard. **READ SDS:** [lamotte.com](http://lamotte.com)

**Emergency information:**  
Chem-Tel USA 1-800-255-3924  
Int'l, call collect, 813-248-0585



Warning! This set contains chemicals that may be harmful if misused. Read cautions on individual containers carefully.  
Not to be used by children except under adult supervision.

## USE OF THE OCTA-SLIDE 2 VIEWER

### PROCEDURE

1.

Insert Salt Water pH Octa-Slide 2 Bar [2165-02] into the Octa-Slide 2 Viewer [1101]

2.

Fill a test tube [0106] to the 10 mL line with sample water.

3.

Add 10 drops of Cresol Red Indicator [2212]

4.

Cap and mix.

5.

Insert test tube into Octa-Slide 2 Viewer [1101].

6.

Hold the Viewer so that non-direct light enters through the back. Match sample color to a color standard. Record as pH.