

Insta-TEST®


25 Pool & Spa Test Strips

- **BIGUANIDE**
- **ALKALINITY**
- **pH**
- **TOTAL HARDNESS**

LaMotte
Just DIP & READ!

Immerse strip for **2 SECONDS**. Remove with pads **face up**. **SHAKE ONCE TO REMOVE EXCESS WATER**. Wait **10 SECONDS** and compare to color chart: Alk > BIG > pH > TH

Alk Alkalinity ppm	0	40	80	120	180	240
BIG Biquanide ppm	0	15	30	50	80	
pH	6.2	6.8	7.2	7.8	8.4	9.0
TH Total Hardness ppm	0	100	250	450	800+	



- Keep wet fingers out of the bottle.
- Close cap tightly after removing strip.
- In pools, immerse strip to a depth of 6".
- In spas, turn off jets and immerse strip to a depth of 6".
- For best results read in natural daylight.
- Store in a cool, dry place.



LaMotte Company, Chestertown, MD 21620 USA
www.lamotte.com/insta

Code 2938

Made in
USA

