


Insta-TEST®

25 Pool & Spa
Test Strips

- ALKALINITY
- pH
- COPPER

LaMotte
Just SWIRL & READ!



Immerse strip. **SWIRL 3 times***. Remove with **pads face up**. **DO NOT SHAKE OFF EXCESS WATER**. Wait 10 seconds for Alkalinity color to develop then read results: Alk > pH > Copper

*In cup-size sample, swirl 5 times.

Alk Alkalinity ppm	0	40	80	120	180	240
			OK			
pH	6.2	6.8	7.2	7.6	8.0	8.4
Cop Copper ppm	0	0.3	0.6	1.0	3.0	

Purple color indicates excessive sanitizer

LaMotte Company, Chestertown, MD 21620 USA Code 3001-G
www.lamotte.com/insta

Made in USA



Drop holding box and dotted tolerance line