



5-WAY
Nitrate, Nitrite, pH, Alkalinity and Total Hardness

25 Test Strips

Code 3038-G

Insta-Test[®] ANALYTIC

NO₃
Nitrate
ppm

Immerse strip. SWIRL 2 TIMES.
Remove with pads face up.
DO NOT SHAKE OFF EXCESS
WATER. Immediately read
Hardness > Alkalinity.
Wait 30 seconds, read pH >
Nitrite > Nitrate.

Fresh & Salt	0	20	40	80	160	200
--------------	---	----	----	----	-----	-----

NO₂
Nitrite
ppm

Fresh & Salt	0	0.5	1	3	5	10
--------------	---	-----	---	---	---	----

pH

- Keep wet fingers out of the vial
- Close vial tightly after removing strip
- Store in a cool, dry place

Fresh	6.0	6.5	7.0	7.5	8.0	8.5	9.0
Salt	6.0	6.5	7.0	7.5	8.0	8.5	9.0

Alk
Alkalinity
ppm

LaMotte Company
Chesterstown, Maryland 21620 USA
www.lamotte.com

Fresh & Salt	0	40	80	120	180	240
--------------	---	----	----	-----	-----	-----

TH
Hardness
ppm

Fresh	0	30	60	120	180
-------	---	----	----	-----	-----

Made in USA



37385 46306 6

Drop holding box and dotted tolerance line