

Pool MGR. ABC Kit

Adds tests for Acid and Base demand plus Chlorine neutralizer

The Pool MGR. 3368-ABC kit is designed for the public pool operator who needs to monitor wide range chlorine (0 - 10 ppm) and accurately adjust pH levels with an acid or base test. The kit includes DPD TesTabs® tests for Free and Total Chlorine as well as other one-step tablet tests for pH, Total Alkalinity, Calcium Hardness and Cyanuric acid. The unique feature of the 3368-ABC is the added dropper bottles that allow the user to determine the acid or base demand using the already reacted pH sample. The extra bottle of chlorine neutralizer helps negate the effect of high chlorine levels on the pH test.

The kit includes easy to understand diagrammed instructions, a saturation index calculator, water quality handbook and the precise Octa-Slide comparator system in a sturdy carrying case. Each unit includes 2 Octa-Slide color bars with 8 translucent color standards for Chlorine and pH. The titration tests, for Alkalinity and Hardness, use a single tablet added to a test sample which is then titrated with pool water to an end-point color. The Cyanuric Acid test employs a tablet that produces a cloudy precipitate in direct proportion to ppm as measured by the disappearing dot method.

Each kit comes with a Pool MGR. water quality handbook. The book is used for reference by lifeguards and maintenance personnel for help with water balance and sanitizer treatment chemicals. Flow charts are included for trouble-shooting water problems.



Code 3368-ABC

TesTabs®



**Now in an easy,
push-through
package!**

 **LaMotte**

PO BOX 329 • CHESTERTOWN • MARYLAND • 21620 • USA
800-344-3100 • 410-778-3100 • fax 410-778-6394 • www.lamotte.com
7.06.3368ABC