

# Insta-TEST®

## 25 Pool & Spa Test Strips


- **BIGUANIDE**
- **ALKALINITY**
- **pH**
- **TOTAL HARDNESS**

**LaMotte**  
Just DIP & READ!

Immerse strip for **2 SECONDS**. Remove with pads **face up**. **SHAKE ONCE TO REMOVE EXCESS WATER**. Wait **10 SECONDS** and compare to color chart: Alk > BIG > pH > TH


<b>Alk</b> Alkalinity ppm	0	40	80	120	180	240
<b>BIG</b> Biguanide ppm	0	15	30	50	80	
<b>pH</b>	6.2	6.8	7.2	7.8	8.4	9.0
<b>TH</b> Total Hardness ppm	0	100	250	450	800+	

LaMotte Company, Chestertown, MD 21620 USA  
[www.lamotte.com/insta](http://www.lamotte.com/insta)



View from above.

- Keep wet fingers out of the bottle.
- Close cap tightly after removing strip.
- In pools, immerse strip to a depth of 6".
- In spas, turn off jets and immerse strip to a depth of 6".
- For best results read in natural daylight.
- Store in a cool, dry place.



Code 2938

Made in **USA**

