

# Insta-TEST<sup>®</sup>

25 Test Strips

WIDE RANGE pH  
TOTAL CHLORINE

 LaMotte

**TIC**


total  
chlorine  
ppm




**pH**



High levels of chlorine (>15 ppm) will fade the pH reading.



Immerse test strip and remove with pads face up. **DO NOT SHAKE OFF** **EXCESS WATER**. Wait 15 seconds and immediately compare to color chart.



View from  
above.

## TIPS

- Keep wet fingers out of the bottle.
- For best results in pools, immerse strip to a depth of 6" (15 cm).
- Close cap tightly after removing strip.
- Store in a cool, dry place.

LaMotte Company  
802 Washington Ave.,  
Chestertown, MD 21620 USA  
410-778-3100 • [www.lamotte.com/insta](http://www.lamotte.com/insta)

Code 2987-G

Made in  
**USA**

