




# Insta-TEST<sup>®</sup>

## 10 Salt Water Test Strips

**SODIUM CHLORIDE**  
1500-5000 ppm

**LaMotte**

**Just DIP & READ!**  
READY IN 20 SECONDS!



Code 2998

Made in  
**USA**

**Salt Water (SODIUM CHLORIDE) ppm**



1500



2000



2500



3000



3500



4000



5000

Dip pad into water sample and immerse for 2 seconds. Remove strip with **pad face up. DO NOT SHAKE OFF EXCESS WATER.** In shade, hold strip level for **20 seconds and compare to color chart.** Discard strip after 30 seconds.

### TIPS

- Keep out of direct sun during testing.
- Keep wet fingers out of the bottle and close cap tightly.
- Store indoors in a cool, dry, dark place.

LaMotte Company, Chestertown, MD 21620  
[www.lamotte.com/insta](http://www.lamotte.com/insta)

