


Insta-TEST[®] 6 Plus

50 Pool & Spa
Test Strips

Plus

- **FREE CHLORINE**
- **BROMINE**
- **TOTAL CHLORINE**
- **ALKALINITY**
- **pH**
- **TOTAL HARDNESS**
- **CYANURIC ACID**

LaMotte
Just DIP & READ!



Code 3028


Made in
USA

Immerse strip for **2 SECONDS**. Remove with **pads face up**. **SHAKE ONCE TO REMOVE EXCESS WATER**.

Read immediately: FCI>TCl>Alk>pH>TH>CyA

FCI

Free Chlorine ppm
(Br)
Bromine ppm



TCl

Total Chlorine ppm



Alk

Alkalinity ppm



pH



Purple color indicates excessive sanitizer

TH

Total Hardness ppm



CyA

Cyanuric Acid ppm



For best results, pH must be between 7.0-8.4

- Keep wet fingers out of the bottle.
- Close cap tightly after removing strip.
- In pools, immerse strip to a depth of 6".
- In spas, turn off jets and immerse strip to a depth of 6".
- For best results read in natural daylight.
- Store in a cool, dry place.



LaMotte Company, Chestertown, MD 21620 USA
www.lamotte.com/insta

Drop holding box and dotted tolerance line