

Insta-TEST[®]


50 Pool & Spa
Test Strips

4
Plus

- **FREE CHLORINE**
- **BROMINE**
- **ALKALINITY**
- **pH**
- **TOTAL HARDNESS**

LaMotte
Just **DIP & READ!**

Immerse strip for **2 SECONDS**. Remove with **pads face up**. **SHAKE ONCE TO REMOVE EXCESS WATER**. Read immediately: FCI > Alk > pH > TH




FCI Free Chlorine (Bromine) ppm	0	0.5	1	3	5	10
	(0)	(1)	(2)	(6)	(10)	(20)
Alk Alkalinity ppm	0	40	80	120	180	240
pH	6.2	6.8	7.2	7.8	8.4	9.0
TH Total Hardness ppm	0	100	250	450	800+	

Purple color indicates excessive sanitizer.

- Keep wet fingers out of the bottle.

- Close cap tightly after removing strip.



- In pools, immerse strip to a depth of 6".

- In spas, turn off jets and immerse strip to a depth of 6".

- For best results read in natural daylight.

- Store in a cool, dry place.

Code 3029

Made in
USA



Drop holding box and dotted tolerance line