



# Easy as 1, 2, 3, 4, 5! Sodium Chloride Testing



1

## Salt, TDS, Temperature TRACER PockeTester™

Order Code 1749-KIT-01

The Salt, TDS, and Temperature TRACER PockeTester was designed for the pool professional. The tester's probe is dipped into a sample of pool water and the results are ready instantly. The Salt PockeTester measures the Sodium Chloride level in salt water pools with a range from 0 to 9,999 ppm, TDS is measured from 0 to 9,999 ppm, and Temperature from 32.0 to 149.0°F or 0.0 to 65.0°C. The PockeTester is packaged in a rugged carrying case with special calibration standards for Salt.

2

## Salt, pH, TDS, Temperature TRACER PockeTester™

Order Code 1766-KIT-01

The Salt, pH, TDS, and Temperature TRACER PockeTester was designed for the pool professional. The tester's probe is dipped into a sample of pool water and the results are ready instantly. The Salt PockeTester measures the Sodium Chloride level in salt water pools with a range from 0 to 9,999 ppm. TDS is measured from 0 to 9,999 ppm, pH 0.00 to 14.00, and temperature from 32.0 to 149°F. The meter can store up to 25 readings. The PockeTester is packaged in a rugged carrying case with special calibration standards for Salt and pH.

Multiple Test Factors Per Meter!

Fast, Reliable Results for Salt Water Pools!



### 3 Insta-TEST® Salt [Sodium Chloride] Test Strips

Order Code 2998-12

The Insta-TEST® Salt [Sodium Chloride] test strips make it easy to test with a one-step procedure for measuring sodium chloride in salt water pools. Just dip and read results in only 20 seconds! The test strip will measure sodium chloride levels from 1500, 2000, 2500, 3000, 3500, 4000, and 5000 ppm. Each bottle includes 10 strips in a convenient, PopTop bottle. A desiccant liner inside the bottle protects the strips from moisture intrusion and UV light. This item is blister-carded for retail sale and packed 12 units per case.

### 4 Insta-TEST® PRO Salt [Sodium Chloride] Test Strips

Order Code 2998-H-12

The Insta-TEST® PRO Salt [Sodium Chloride] test strip was designed for the pool professional to measure Sodium Chloride levels from 1500, 2000, 2500, 3000, 3500, 4000, and 5000 ppm in salt water pools. The Sodium Chloride test strip is a simple dip and read method with results in 20 seconds. Each bottle contains 50 strips packaged in a waterproof PopTop bottle with English, Spanish, and French instructions on the label. The bottle has a molded desiccant liner, which protects the strips from moisture and UV light. This item is packed 12 bottles per case.



### 5 Sodium Chloride Test Kit

Order Code 3156

The Sodium Chloride Test Kit is an easy-to-use drop count titration kit for salt water pools. The salt content of the pool is measured by counting each drop of titrant added to the sample tube. Count the drops and multiply that number by 200 – that's the salt level in the pool. Simple! The kit comes in a sturdy, plastic case with two 30mL salt titrant bottles, one 15mL chloride reagent bottle, and one clear sample tube with cap.



Water Testing Leader Since 1919!

LaMotte Company • PO Box 329 • Chestertown • Maryland • 21620 • USA  
t: 800-344-3100 • 410-778-3100 • f: 410-778-6394 • [www.lamotte.com/pool](http://www.lamotte.com/pool)