

Code 2933-G

25 Test Strips

DRINKING WATER 6



Nitrate, Nitrite, pH, Free Chlorine, Total Chlorine & Total Hardness

Insta-Test[®] ANALYTIC

Immerse strip for 2 seconds.
Remove with pads face up.
SHAKE ONCE TO REMOVE EXCESS WATER. Immediately read **Free Chlorine, Total Chlorine, Total Hardness** and **pH**. Wait 30 seconds, then read: **Nitrite > Nitrate**.

- Keep wet fingers out of the vial
- Close vial tightly after removing strip
- Store in a cool, dry place

LaMotte Company
Chesterstown, Maryland 21620 USA
www.lamotte.com



Lot# 93912 Exp. 1/22

Free Chlorine ppm	0	0.5	1	3	5	10
Total Chlorine ppm	0	0.5	1	3	5	10
Total Hardness ppm (gpg)	0 (0)	50 (3)	100 (5.8)	200 (11.7)	400 (23)	
pH	4	5	6	7	8	9 10
Nitrite as NO ₂ -N ppm	0	0.5	1	5	10	
Nitrate as NO ₃ -N ppm	0	5	10	25	50	