

Insta-TEST[®]

PRO400+

Free Chlorine (Bromine)
Cloro libre (Bromo)
Chlore Libre (Brome)

Total Chlorine
Cloro total
Chlore total

Alkalinity
Alcalinidad
Alcalinité

pH
pH
pH

100 Test Strips
Tiras Reactivas
Bandelettes d'Analyse

Immerse pool & spa test strip for 2 seconds. Remove with pads face up. **SHAKE ONCE TO REMOVE EXCESS WATER.** Read immediately:


FCI > TC > Alk > pH

Sumerja la tira reactiva para piscinas y spas durante 2 segundos. Sacarla del agua con las almohadillas hacia arriba. **SACUDIR UNA VEZ PARA ELIMINAR EL EXCESO DE AGUA.** Comparar el color inmediatamente:

FCI > TC > Alk > pH

Immergez la bandelette d'analyse pour piscine et spa pendant 2 secondes. Retirer la face au dessus. **SECOUER POUR ÉLIMINER L'EXCÉDENT D'EAU.** Lecture immédiate:

FCI > TC > Alk > pH



Free Chlorine (Bromine) Cloro libre (Bromo) Chlore libre (Brome)

FCI	ppm	OK	0	0.5	1	3	5	10
(Br)	(o)	(1)	(2)	(6)	(10)	(20)		

Total Chlorine Cloro total Chlore total

TCI	ppm	OK	0	0.5	1	3	5	10
-----	-----	----	---	-----	---	---	---	----

Alkalinity Alcalinidad Alcalinité

Alk	ppm	OK	0	40	80	120	180	240
-----	-----	----	---	----	----	-----	-----	-----

pH	6.2	6.8	7.2	7.8	8.4	9.0
----	-----	-----	-----	-----	-----	-----

Purple color indicates excessive sanitizer.
El tono morado indica un exceso de desinfectante.
Si violeta, cloro ou brome trop élevé.

LaMotte Company
802 Washington Avenue, Chestertown, MD 21620 USA
www.lamotte.com/insta

Code 2978

