

Sodium Chloride Test Kit Code 3156




802 Washington Ave. · Chestertown · Maryland · 21620 · USA 800-344-3100 · +1 410-778-3100 · Fax 410-778-6394 Visit us on the web at www.lamotte.com



WARNING: Cancer and Reproductive Harm www.P65Warnings.ca.gov

## **Test Procedure**

- 1. Fill the tube (0715) to the 5 mL line with the sample water.
- 2. Add three drops of \*Chloride Reagent #1 [4504] to sample. Swirl to mix. Solution will turn yellow.
- 3. Holding \*Salt Titrant (3741LWT) in a vertical position, add one drop at a time, swirling to mix, until the color changes from yellow to milky orange. Count the number of drops required to reach the final color. Add titrant slowly. allowing each drop to form fully on the tip before dispensing. Rapid titration with incomplete drops will result in erroneous high readings.



\*Salt Titrant will stain. Avoid contact with skin. Place tip of titrant bottle well into titration tube while dispensing.



\*Reagent is a potential health hazard. READ SDS: lamotte.com **Emergency information:** Chem-Tel USA 1-800-255-3924 Int'l. call collect. 813-248-0585





