




QUANTITY	CONTENTS	CODE
15 mL	*Sulfite Reagent A	*7327-E
15 mL	Sulfite Reagent B	7328-E
60 mL	Sulfite Reagent C	7329PS-H
1	Test tube, 10.5 mL, w/cap	0818
1	Pipet, plain, glass	0342

To order individual reagents or test kit components, use the specified code number.

*Reagent is a potential health hazard. **READ SDS:** lamotte.com

Emergency information:
Chem-Tel USA 1-800-255-3924
Int'l, call collect, 813-248-0585



PROCEDURE

1. Add 10 drops of *Sulfite Reagent A [7327] to the empty test tube [0818].
2. Fill tube to 10.5 mL line with sample water.
3. Add 5 drops of Sulfite Reagent B [7328]. Cap and swirl to mix.
4. Fill pipet [0342] with Sulfite Reagent C [7329]. While gently swirling tube, add Sulfite Reagent C, one drop at a time, until sample turns a faint but permanent blue. Count the drops added. Hold pipet vertically.
5. Multiply number of drops added in Step 4 by 5. Record as ppm Sulfite [SO₃⁻²].

drops added x 5 = ppm SO₃⁻²

LAMOTTE COMPANY | 802 Washington Avenue | Chestertown, Maryland | 21620 USA
800.344.3100 | +1 410.778.3100 (Outside USA) | Fax 410.778.6394 | lamotte.com

©2023 LaMotte Company, All Rights Reserved 67175-01 04.24.2023